

TELEMECANIQUE Auxiliary contacts



Description	Article
Auxiliary Contact 1 N/C Fault + 1 N/O Handle Position LUA1C11	TQLUA1C11
Auxiliary Contact 1 N/O + 1 N/C LUFN11	TQLUFN11
Auxiliary Contact 1 N/O Fault + 1 N/O Handle Position LUA1C20	TQLUA1C20
Auxiliary Contact 2 N/C LUFN02	TQLUFN02
Auxiliary Contact 2 N/O LUFN20	TQLUFN20

Disclaimer: The content of this document has been composed with the utmost care. However, it is possible that certain information changes over time, becomes inaccurate or incomplete. ERIKS does not guarantee that the information provided on this document is up to date, accurate and complete; the information provided is not intended to be advice. ERIKS shall never be liable for damage resulting from the use of the information provided.